FIG.1A



FIG.1B



FIG.2


38
12,14
COIN/BILL ACCEPTOR
40
INPUT DEVICES
44
46
RAM
PROCESSOR
DISPLAY DEVICES
48
ROM
30,32
SOUND CARD
42
SPEAKERS
36
VIDEO CONTROLLER
54
TOUCH SCREEN CONTROLLER
52
TOUCH SCREEN
50

US6007427

FIG.3A



T0S00T "9T92Z660

FIG.3B



TOSOOT "9T92Z660

FIG.3C



FIG.4

100

102	102a MONETARY INPUT	102b PROCESSOR ADAPTED TO	102c TO INCREASE LINES	102d BET INCREMENT	102e TO INCREASE BET
104	1 CREDIT	ACTIVATE ALL PAYLINES BUT PLAYER	N/A	$ VALUE OF CREDIT / # OF PAYLINES	INPUT ANOTHER CREDIT, CHOOSE BET PER LINE SELECTOR
106	1 CREDIT	ENABLES ACTIVATION OF ALL PAYLINES BUT PLAYER SELECTABLE	CHOOSE SELECT LINES SELECTOR	$ VALUE OF CREDIT / # OF PAYLINES SELECTED	INPUT ANOTHER CREDIT, CHOOSE BET PER LINE SELECTOR
108	1 CREDIT	ACTIVATES TWO PAYLINES ON MACHINES WITH MULTIPLES OF TWO PAYLINES	INPUT ANOTHER CREDIT, CHOOSE SELECT LINES SELECTOR	$ VALUE OF CREDIT/2; 50¢ GAME FOR A DOLLAR MACHINE	INPUT ANOTHER CREDIT, CHOOSE BET PER LINE SELECTOR
110	1 CREDIT	ACTIVATES FOUR PAYLINES ON MACHINES WITH MULTIPLES OF FOUR PAYLINES	INPUT ANOTHER CREDIT, CHOOSE SELECT LINES SELECTOR	$ VALUE OF CREDIT/4; 25¢ GAME FOR A DOLLAR MACHINE	INPUT ANOTHER CREDIT, CHOOSE BET PER LINE SELECTOR
112	1 CREDIT	ACTIVATES TEN PAYLINES ON MACHINES WITH MULTIPLES OF TEN PAYLINES	INPUT ANOTHER CREDIT, CHOOSE SELECT LINES SELECTOR	$ VALUE OF CREDIT/10; 10¢ GAME FOR A DOLLAR MACHINE	INPUT ANOTHER CREDIT, CHOOSE BET PER LINE SELECTOR
114	1 CREDIT	ACTIVATES TWENTY PAYLINES ON MACHINES WITH MULTIPLES OF TWENTY PAYLINES	INPUT ANOTHER CREDIT, CHOOSE SELECT LINES SELECTOR	$ VALUE OF CREDIT/20; 5¢ GAME FOR A DOLLAR MACHINE	INPUT ANOTHER CREDIT, CHOOSE BET PER LINE SELECTOR



FIG.5

US 6,866,583 B2